

ZUER 卓耳

Wireless HiFi Headphone

Genuine sound



<http://www.zuer3c.com/>

EN Go to the user manual
CN 访问使用说明

ZUER 卓耳



<http://www.zuer3c.com/>




Dongguan Joy2Hear Electronics Co.,
LtdNo.38 Chuangye Road, Jiaolian Community,Wanjiang Subdistrict,
Dongguan City, Guangdong Province China (PRC)

Packaging List

- ×1 [Image of user manual]
- ×1 [Image of headphones]
- ×1 [Image of carrying case]
- ×1 [Image of USB-C to USB-A cable]
- ×1 [Image of 3.5mm audio cable]

Wireless Connection



Instructions

- Power button**
[Image of power button]
- Play/Pause** [Image of play/pause button] ×1 **Answer/End** [Image of answer/end button] ×1
- Volume Control**
[Image of volume control buttons]

- Previous/Next Track**
[Image of previous/next track buttons]
- Type-C Port** [Image of Type-C port]
- 3.5mm Audio Jack**
[Image of 3.5mm audio jack]
- Switch ANC Modes**
[Image of ANC mode switch]
ANC Mode ×1
Transparency Mode
- ANC Mode**
ANC Mode ×1
Transparency Mode
- Voice Assistant**
[Image of voice assistant button]

- Spatial Audio**
[Image of spatial audio button]
Normal Mode ×2
Spatial Audio Mode
- Game Mode**
[Image of game mode button]
Music mode ×3
Game Mode
- EQ Switching**
[Image of EQ switching button]
EQ1 ×2
EQ2
- Charging indicator**
[Image of charging indicator]
Flashing red
Steady red
OFF

Important Notes

I. Safety Instructions
Electrical Safety: Use only the original or certified charging cable and adapter. Avoid charging or using the headphones in humid environments (e.g., bathrooms) to prevent short circuits or electric shock.
Battery Care: If the headphones will not be used for an extended period, ensure the battery level is around 50% and power them off for storage. Do not leave the headphones in high-temperature environments (e.g., a car under direct sunlight) to prevent battery damage and potential safety hazards.
Operating Environment: Use and store the headphones in a cool, dry place. Keep them away from open flames or high-temperature heat sources.
Children and Pets: Store the headphones and accessories out of reach of children and pets to prevent the risk of swallowing small parts or entanglement in cables.

II. Usage and Wearing
Volume Control: To prevent hearing damage, do not use the headphones at high volume for prolonged periods. It is recommended to follow the "60/60 Rule": volume should not exceed 60% of the maximum level, and continuous use should not exceed 60 minutes.
Situational Awareness: When walking, driving, or engaging in activities that require high concentration, do not use the headphones or keep the volume low to ensure awareness of your surroundings and personal safety.
Comfortable Fit: Adjust the headband and ear cups to a comfortable position, avoiding excessive clamping force. If you experience discomfort in your head or ears, discontinue use and take a break.
Hygiene and Cleaning: Regularly clean the ear cups and headband with a soft, dry cloth. Avoid using alcohol or chemical solvents directly on leather surfaces to prevent aging or discoloration.

III. Maintenance and Care
Proper Storage: When not in use, place the headphones in their carrying case or hang them on a dedicated stand. Avoid compressing or bending the headband.
Physical Protection: Avoid dropping, impacting, or forcefully pulling the cables (for wired models) to prevent damage to internal components.
Cleaning Methods: Removable ear cushions can be cleaned according to the specific instructions for their material. Clean the main body of the headphones with a slightly damp, soft cloth and ensure it is thoroughly dried afterwards.
Disclaimer: The company shall not be held liable for any product damage or personal injury resulting from failure to follow the above precautions.

Specifications

Product Name:	ZUER Vogues AC169
Brand name:	ZUER
Product model:	AC169
Wireless Version:	6.0
Wireless range:	10m
Horn resistance:	32Ω±15%
Battery:	Lithium polymer battery
Charging input:	5V
Charging time:	150 Minutes
Battery life (with noise cancellation on):	Play at 50% volume for 75 hours; Play at 100% volume for 50 hours
Battery life (with noise cancellation off):	Play at 50% volume for 80 hours; Play at 100% volume for 60 hours
Battery Capacity:	800 mAh